


SELSTAD



Posisjoner anlegg Ålvund



Komponent	Posisjon N	Posisjon Ø	Komponent	Posisjon N	Posisjon Ø
Line 1	62°52.438	8°24.608	Hjørne SØ	62°52.722	8°24.431
Line 2	62°52.390	8°24.325	Hjørne SV	62°52.715	8°23.483
Line 3	62°52.419	8°24.203	Hjørne NV	62°52.824	8°23.479
Line 4	62°52.452	8°24.085	Hjørne NØ	62°52.836	8°24.426
Line 5	62°52.506	8°23.965			
Line 6	62°52.554	8°23.847	Senter Flåte	62°12.686	5°25.492
Line 7	62°52.600	8°23.722	FL1	62°12.566	5°25.436
Line 8	62°52.623	8°23.606	FL2	62°12.582	5°25.364
Line 9	62°52.654	8°23.475	FL3	62°12.674	5°25.249
Line 10	62°52.704	8°23.306	FL4	62°12.767	5°25.294
Line 11	62°52.770	8°23.211	FL5	62°12.834	5°25.524
Line 12	62°52.851	8°23.224	FL6	62°12.808	5°25.650
Line 13	62°53.044	8°23.451	FL7	62°12.640	5°25.881
Line 14	62°53.081	8°23.581	FL8	62°12.581	5°25.739
Line 15	62°53.087	8°23.709			
Line 16	62°53.100	8°23.837			
Line 17	62°53.097	8°23.957			
Line 18	62°53.113	8°24.069			
Line 19	62°53.108	8°24.188			
Line 20	62°53.094	8°24.321			
Line 21	62°53.062	8°24.435			
Line 22	62°52.861	8°24.854			
Line 23	62°52.779	8°25.016			
Line 24	62°52.698	8°25.143			